



WICHTIGER MONTAGEHINWEIS

WM 6527 Anzugsdrehmoment 300 Nm

VORSICHT: Bei Fahrzeugen mit 44 mm Flanschdurchmesser - Mutter - Radnabe sicherstellen, dass die Beilegscheibe - Mutter - Radnabe mit der flachen Seite zum Radlager eingebaut wird.

Radnabe einbauen.

Mutter – Radnabe in 5 Stufen festziehen:

1. Stufe 1: Radnabe 5-mal drehen.
2. Stufe 2: Radnabe bei Festziehen der Mutter – Radnabe mit 200 Nm in die entgegengesetzte Richtung drehen.
3. Stufe 3: Radnabe 5-mal drehen.
4. Stufe 4: Radnabe bei Festziehen der Mutter – Radnabe auf das vorgeschriebene Drehmoment in die entgegengesetzte Richtung drehen.





IMPORTANT INSTALLATION NOTICE

WM 6527 Tightening torque 300 Nm

VATTENTION: For cars with flange diameter 44mm - nut-wheel hub – please secure, that the washer is mounted with the flat side facing the wheel bearing.

Mounting wheel hub:

Nut – wheel hub, tightening in five steps:

1. Turn the wheel hub five times
2. Tighten the wheel hub with 200 Nm in the opposite direction
3. Turn the wheel hub five times
4. Turn the wheel hub with the stipulated tightening torque in the opposite direction
5. Turn the wheel hub five times

